Do not use this for	UNITED S DEPARTMENT OF BUREAU OF LAND SUNDRY NOTICES AND m for proposals to drill or to e "APPLICATION FOR PER	THE INTERIOR MANAGEMENT REPORTS ON WE o deepen or reentry	to a different reservor	Division Budge Ex 5. Lease De <u>+C-03</u> 6. If Indian, r.	signation and Serial No. 1736(b) N'M b Hill F Allottee or Tribe Name att
	7. If Unit of	CA, Agreement Designation			
Type of Well Oil Well Well X Well X Well Amoco Produ Address and Telephone No P O Box 489 Location of Well (Footage	<u>Gillu</u> 9. API Well <u>30-02</u> 10. Field and	8. Well Name and No. <u>Gillully B Federal</u> 9. API Well No. RA A #6Y <u>30-025-06201</u> 10. Field and Pool, or Exploratory Area Lince Manus Markets C B SA			
Letter A, 3		r Parish, State			
CHECK A	PPROPRIATE BOX(s) TO	INDICATE NATUR	RE OF NOTICE, REP	ORT, OR O	THER DATA
TYPE OF S	DN				
X Notice of	Intent	Abandonmer	it	ř n	e of Plans
	t Report	X Recompletio	ck	Non-R	Construction Coutine Fracturing Shut-Off
🗌 Final Aba	ndonment Notice	Casing Repa		Conve	rsion to Injection lose Water rr results of multiple completion on Well or Recompletion Report and Log form.
give subsurface locati See a	pleted Operations (Clearly state all pertine ons and measured and true vertical depths ttached description (g the first week of	s for all markers and zones pe	ertinent to this work.)*		
				RO	RECEIVE

,

-

14 I hereby certify that the foregoing forme and correct Signed	Title _	Sr. Business Analyst	Date
This space ORICE SCD. ALEXISC. SWOBODA	Title _	PETROLEUM ENGINEER	Date 11/29/90
Conditions of approval, if any:			

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any talse. fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See instruction on Reverse Side

.

7.A Morement GC

November 21, 1996

Gillully B Federal Well #6Y Unit A, 390' FNL & 660' FEL, Section 21, T-20-S, R-37-E Lea County, New Mexico Eumont Formation Proposed Workover Procedure

Objective: Isolate the Grayburg and set up the Eumont for stimulation/production.

- 1. Hold a pre-job safety meeting with all personnel on lease. Ensure that all personnel on lease are aware of job procedures and egress routes.
- 2. Note and record tubing and casing pressures.
- 3. MIRU Service Rig.
- 4. Ensure well is dead, **if necessary** kill well with clean filtered 2 % KCL water.
- 5. Unset packer, POOH with tubing and packer, lay down packer.
- 6. RIH with a CIBP and set at 3700', dump 35' cement on top of CIBP. Grayburg zone is to be abandoned.
- 7. RIH with tubing, packer and F nipple, set packer at 2575'.
- 8. Swab well evaluate.
- 9. Rig out/move off, TOTP.