

ATTACHMENT
FORM C-103

17. (Cont'd)

(15) Clean 2-1/16 tubing (if needed) and test tubing to 600 psi.

(16) GIH with production equipment on long string as follows:

- A) Seal assembly for Model "C" packer.
- B) 1.43 "F" Nipple
- C) "ER" Receptacle and swage to 2-1/16".

(17) GIH with short string, open ended with 1.43" "F" nipple on bottom, to 5550'.

(18) Swab short string and put Blinbry on production.

(19) Acidize Tubb (6123-6189) with 2000 gals 20% inhibited HCl Acid containing:
2 gal/1000 foaming Fluorosur Factant, 10 lb/1000 fluid loss addition.

Treat at 6-8 BPM with BHTP=5000 as follows:

- A) Pump 500 gal 5% KCl water w/2 gal/1000 clay stabilizer
- B) Pump 8000 gals acid
- C) Flush with 800 gals 5% KCl water w/2 gal/1000 non emulsifier.
- D) Shut well in for 30 min.

(20) Swab Tubb back and return to production.