

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>

5. State Oil & Gas Lease No.
Fee

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		NONE
3. Address of Operator		8. Farm or Lease Name
TEXACO Inc.		V. M. Henderson
4. Location of Well		9. Well No.
UNIT LITR H 1980 FEET FROM THE North LINE AND 660 FEET FROM		10. Field and Pool, or Wildcat
THE East LINE, SECTION 30 TOWNSHIP 21-S RANGE 37-E NMPM.		Paddock
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3496' (D. F.)		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>
Abandon Drinkard & Re-complete in the Paddock Zone.	

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to do the following work on subject well:

1. Pull rods and tubing, prepare to abandon the Drinkard zone, and re-complete in the Paddock zone.
2. Set Cast Iron bridge plug at 6500' and cap with approx. 15' of Hydromite.
3. Perforate 5 1/2" Casing with 2 jet shots per foot from 5166' to 5178'.
4. Acidize with 500 gals 15% NE acid, flush with lease crude, re-acidize with 1000 gals 15% NE acid.
5. Swab well, Test, place well on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. D. Raymond TITLE Assistant District Superintendent DATE May 18, 1965

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: