

NO. OF COPIES RECEIVED		
DISTRIBUTION		
WITNESSES		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL, RE-DRILL, DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>TEXACO Inc.</b>		8. Farm or Lease Name <b>V.M. Henderson</b>
3. Address of Operator <b>P. O. Box 728 Hobbs, NM 88240</b>		9. Well No. <b>5</b>
4. Location of Well UNIT LETTER <b>B</b> , <b>1980</b> FEET FROM THE <b>East</b> LINE AND <b>660</b> FEET FROM THE <b>North</b> LINE, SECTION <b>30</b> TOWNSHIP <b>21 S</b> RANGE <b>37 E</b> N.M.P.M.		10. Field and Pool, or Wildcat <b>Paddock, Eumont Queen Gas</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3996 DF</b>		12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE DEPTH <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods & tubing from both zones and parallel anchor @ 3515.
2. Set RBP @ 5000 and dump 2 sx sand no plug.
3. Squeeze 7" casing perforations 3506-3581 (Eumont Queen) w/250 sx Class C cement.
4. Drill out cement and test to 500# and pull RBP.
5. Pull packer @ 5100' and clean out to TD @ 5205.
6. Abandon Eumont Queen Gas and return Paddock to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE Asst. Dist. Supt. DATE January 22, 1975

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: