

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

JUN 13 9 15 AM '66

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER T.A.	7. Unit Agreement Name
2. Name of Operator Amerada Petroleum Corporation	8. Farm or Lease Name J.G. Hare
3. Address of Operator P.O. Box 668 - Hobbs, New Mexico	9. Well No. 6
4. Location of Well UNIT LETTER L , 1980 FEET FROM THE South LINE AND 760 FEET FROM THE West LINE, SECTION 33 TOWNSHIP 21S RANGE 37E NMPM.	10. Field and Pool, or Wildcat Wantz Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3462' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pull rods, pump & tubing. Set bridge plug at 6900' with one sack cement on top. Load casing with water. Run Gamma Ray Neutron log from surface to 6900' with Detail from 2500' to 6900'. Locate and squeeze hole in 5-1/2" casing. Drill out cement and pressure test casing. Block squeeze San Andres Zone. Perforate San Andres zone subject to logs from 4165' to 4200'. Swab Test. Acidize if necessary. Swab test. Run rods pump and tubing & restore well to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *D. C. L. S. S.* TITLE District Superintendent DATE 6-9-66

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: