

ATTACHMENT TO C-103

Mark Owen #6

3-28-83

Pump 50 sacks Class "C" with Halad 4 & 25 sacks Class "C" neat. Reverse cement. Drill cement retainer and cement. Drill cement retainer set at 2710' and cement. Circulate hole clean. Held 500# pressure on casing for 1 hour with Tony Plattsmier on location. Circulate sand off RBP at 5772' and POH with RBP. GIH with tubing and EL receptical. Circulate hole. Latch onto packer at 6293' and test tubing to 1000#. Pull blanking plug out. Turned well down gas sales line and left flowing. Clean location. Complete after resqueezing and cement squeeze water flow.

RECEIVED  
MAR 29 1983  
U.S. D.  
TREASURY OFFICE