Cities Service Oil Company #1 Owen - Workover procedure - continued

- 7. If commercial production in found in the Granite Wash or Wantz Abo, apply for commission approval to dually produce the Blinebry and Granite Wash or Wantz Abo, obtain potentials and put on production.
- 8. If neither Granite Wash or Wantz Abo are productive, set a CIBP above the Wantz Abo perfs and dump cement on top of the CIBP. Reperforate the Drinkard zone as determined by logs, treat and test. Run production equipment and dually complete with the Blinebry zone.
- 9. If production is found in the Granite Wash or Wantz Abo we propose to apply for commission approval to perforate the Drinkard zone, commingle confluently with the Blinebry zone and dually produce along with either the Granite Wash or Wantz Abo zone. This approval will be applied for at a later date.