

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.B.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL UP TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - II" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Exxon Corporation	8. Farm or Lease Name Paddock Unit
3. Address of Operator Box 1600, Midland, Texas 79702	9. Well No. 3
4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>735</u> FEET FROM THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>21-S</u> RANGE <u>37-E</u> NADPH.	10. Field and Pool, or Wildcat Paddock
15. Elevation (Show whether DF, RT, CR, etc.) 3385	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 4960. Spot 10 Sx. Plug at 4960'.
2. Spot 20 Sx. Plug at 3800, 20 Sx. Plug at 3300'. 35 Sx. Plug at 2850'.
3. Cut and pulled 5 1/2" CSG at 1120'.
4. Spot 70 Sx. Plug at 1200'. Top of CMT at 900'.
5. Spot 35 Sx. Plug at 350'. 10 Sx. Plug at surface.
6. Install dry hole marker as required by NMOCC.
7. C-103 will be forwarded when location is cleaned and leveled.

FRW - 7-9-79

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>C. J. Jackson</u>	TITLE <u>Unit Head</u>	DATE <u>8-24-79</u>
APPROVED BY <u>Eddie W. Day (HAP)</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u>AUG 10 1983</u>
CONDITIONS OF APPROVAL, IF ANY:		