

1-23-86

PA Procedure

J R Cone

Jalomat Yates Tr 1 #4-J 13-22-35-

10 4 surf plug & marker

8 $\frac{3}{8}$ at 305' w/700x - circ

Perf below shoe of surf & egg - leave 100' ^{plug} inside pipe

set 100' plug top salt approx 1675'

set CIBP above yates w/35' cnt or
set cnt plug & tag

Top yates 3662

Yates perf 3662 - 3926
3663 - 3846

5 $\frac{1}{2}$ at 400.2' w/800x