

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Mining and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240  
DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210  
DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-08824
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name State A AC 2
8. Well No. 12
9. Pool Name or Wildcat Jalmat Tansill Yates 7 Rvrs

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	2. Name of Operator Clayton Williams Energy, Inc.
3. Address of Operator Six Desta Drive, Suite 3000 Midland, Texas 79705	4. Well Location Unit Letter <u>I</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>7</u> Township <u>22S</u> Range <u>36E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) GR - 3621

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Work will begin upon OCD approval.

- 1) MIRU Workover rig. Release 7" packer @ 2864'. P00H w/tbg and packer
- 2) Set CIBP @ 2900' w/35' cement on CIBP.
- 3) Load Hole from CIBP to surface w/10 PPG gelled brine.
- 4) Perforate the 7" casing @  $\pm$  290;.
- 5) Circulate cement down the 7" casing and up the 7"/9-5/8" annulus to surface. (100 ax Class C)
- 6) Cut all csg 3' below GL. Install P & A marker. Cut and remove all deadmen. Remove all junk from location.

\*Plug and Abandon Wellbore\*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE David G. Grafe TITLE Senior Operations Engineer DATE 12-21-94  
TYPE OR PRINT NAME David G. Grafe TELEPHONE NO. 682-6324

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: