

Continued

#17.

12. Dowell acidz Set III w/10,000 gals 15% NEFEHCL acid* at 3-5 BPM. Drop 100 1.1 S. G. Ball sealers spaced evenly thru out acid. If ball out occurs, surge off balls & continue w/ treatment. Flush to btm perf w/2% KCL wtr**.
13. Flow or swab back load. Evaluate FE.
14. Rlse pkr, lwr & circ sd off RBP. Latch RBP & POH w/2-3/8 WS, pkr & RBP.
15. RIH w/tbg & pmpg setup, TX @ 7310", SN @ 7275'. POP & test.

RECEIVED
APR 22 1985
G.C.D.
HABES OFFICE