

- 12-15-78 Pulled and LD tbg to 4750' (btm of shoe). Pumped 91 bbls 10# brine water to load hole. Spotted 3 sx cotton seed hulls and 3 sx paper. Spotted 170 sx cmt. Pulled out 40 stds tbg. Waited 3 hrs. Ran tbg to 4750'. Did not tag cement. Spotted 5 sx cotton seed hulls and 5 sx paper, followed by 100 sx cement. Pulled out 40 stds tbg.
- 12-16-78 Tagged plug @ 4570' (180' of plug). Spotted 60 sx cement @ 900'. Put 10 sk plug in surface.
- 12-18-78 Installed dry hole marker.

xc: Working Interest Owners