

9. 9-5/8 inch surface casing should be set in the Rustler Anhydrite formation and cement circulated to the surface. If surface casing is set at a lesser depth the 4-1/2 inch casing must be cemented from the casing shoe to the surface or cemented to the surface through a stage tool set at least 50 feet below the top of the Rustler, after cementing around the shoe with sufficient cement to fill to the base of the salt section.

FILED 1978
INFORMATION COMM.
E. 2013, H. 20.

473