Form 3180-5 (June 1990)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

O BOXIGIOSO NO. 1004-0135 BOXIGIOSO NO. 1004-0135 FEDURA: MEXIGO 88240

		LC 0634580
SUNDRY NOTICE	S AND REPORTS ON WELLS	6. If Indian, Allottee or Tribe Name
o not use this form for proposals to drill or to deep		
Use "APPLICATION FOR PERMIT for	such proposals	7. If Unit of CA, Agreement Designation
SUBMIT IN TRIPLICATE		
ype of Well		<del></del>
X ON Gas		
Well Well Other  Name of Operator		8. Well Name and No. Warren Unit
•		Well #64 9. API Well No.
CONOCO INC. dress and Telephone No.		
(915) 684 - 6381 10 DESTA DR. STE 100W, MIDLAND, TX. 79705 (915) 686 - 5424		30 026 26208 10. Field and Pool, or Exploratory Area
Location of Well (Footage, Sec., T., R., M., or Survey Description)		Warren Blinebry Tubb Oil & Ges
Sec 28, T20S, R38E, Unit Ltr A SURFACE: 660 FNL & 660 FEL TD: Same		11. County or Parish, State
		LEA, NM
CHECK APPROPRIATE BOX(s) TO IND	ICATE NATURE OF NOTICE, REPORT, C	OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	N
Notice of Intent	Abandonment P&A	Change of Plans
	Recompletion	New Construction
X Subsequent Report	Plugging Back	Non-Routine Fracturing
	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Cesing	Conversion to Injection
	X Other - Add perfs & acidize	Dispose Water
		(Piolo: Report results of multiple completion on Well
	<del></del>	
Describe Proposed or Completed Operations (Clearly state all per directionally drilled, give subsurface locations and measured 5-6-96: Clean out hole, hot oil. Perforate 2 spf @	and true vertical depthe for all markets and zones persistent to a	Computer or Recomptation Report and Log form.)  So of starting any proposed work. If well is his work.)*
directionally drilled, give subsurface locations and measured  5-6-96: Clean out hole, hot oil. Perforate 2 spf @	and true vertical depthe for all markets and zones persistent to a	e of starting any proposed work. If well is his work.)*
directionally drilled, give subsurface locations and measured  5-6-96: Clean out hole, hot oil. Perforate 2 spf @	and true vertical depthe for all manners and zones persistent to a  6672-92'.  zed new Tubb perfs w/3000 gals t5% NEFE HCL &	e of starting any proposed work. If we'll is his work.)*
5-8-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6650', acidiz	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & ction.	e of starting any proposed work. If we'll is his work.)*
5-6-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6650', acidiz 5-8-96: Run in hole with pump, put well on produc	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & 1 ction.  3/8" tubing set @ 6706'.	e of starting any proposed work. If well is his work.)*  75 B.S.
5-8-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6850', acidiz 5-8-96: Run in hole with pump, put well on produc	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & 1 ction.  3/8" tubing set @ 6706'.	e of starting any proposed work. If well is his work.)*
5-6-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6850', acidiz 5-8-96: Run in hole with pump, put well on produc	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & 1 ction.  3/8" tubing set @ 6706'.	e of starting any proposed work. If well is his work.)*  75 B.S.
5-6-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6650', acidiz 5-8-96: Run in hole with pump, put well on produc	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & ction.  3/8" tubing set  6706'.	ACCEPTED FOR RECORD  JUL 1 1996
5-6-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6850', acidiz 5-8-96: Run in hole with pump, put well on produc Blinebry perfs: 6012-6143', Tubb 6637-6804'., 2 3 1 hereby certify that the foodpoing is total and cabust Signed	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & ction.  3/8" tubing set  6705'.	e of starting any proposed work. If well is his work.)*  75 B.S.
5-8-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6850', acidiz 5-8-96: Run in hole with pump, put well on product Blinebry perfs: 6012-6143', Tubb 6637-6804'., 2 3 signed    Thereby certify that the fueboring is the and output Signed    (This space for Federal or State office use)	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & ction.  3/8" tubing set  66706'.	ACCEPTED FOR RECORD  JUL 1 1996  Cate 74-96
5-8-96: Clean out hole, hot oil. Perforate 2 spf @ 5-7-96: Set RBP @ 6700'. Packer @ 6850', acidiz 5-8-96: Run in hole with pump, put well on product Blinebry perfs: 6012-6143', Tubb 6637-6804'., 2 3 signed    Thereby certify that the fueboring is the and output Signed    (This space for Federal or State office use)	and true vertical depthe for all manners and zones persistent to a 6672-92'.  zed new Tubb perfs w/3000 gals 15% NEFE HCL & ction.  3/8" tubing set  6706'.	ACCEPTED FOR RECORD  JUL 1 1996

\*See Instruction on Reverse Side