

EVA QWWS A #2

4. Swab back load and acid water. If well will not flow, POH w/tbg and pkr. RIH w/pmpg setup as follows: 2-7/8" TS 6670, SN 6640, TAC 6500. RIH w/1 1/2" pump on 76 rod string. RR