10. ND BOP. NU WH.

11. RIH with rods and pump as follows:

2 $\frac{1}{2}$ x 1 $\frac{1}{4}$ x 26' RHBC (HVR) Pump 1 1" Rod 26K Shear Tool ± 20 1" Rods ± 122 $\frac{3}{4}$ " Rods ± 56 $\frac{7}{8}$ " Rods Pony rods as needed

Ĩ

Space out pump. Hang well on.

12. RDMO pulling unit. Turn well over to production. Put on test and report rates and pressures through computer system for 21 days.

Approved: A. Lee

Date:

Ř,