

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-31986
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2667
7. Lease Name or Unit Agreement Name Ottawa State
8. Well No. 1
9. Pool name or Wildcat Wildcat Delaware

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator WTT 1993, Ltd	
3. Address of Operator C/O 1306 Meadow Lane Roswell, NM 88201	
4. Well Location Unit Letter <u>K</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>3</u> Township <u>22 South</u> Range <u>32 East</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3797' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: Continuous Operations <input checked="" type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

September 1, 1993 thru September 19, 1993

Well shut in waiting on rig.

September 20, 1993

Move in and rig up 55 Well Service Pulling Unit. Move in and rig up reverse equipment. Nipple up BOP. Make up 7 7/8" bit and go in hole with drill collars. Pick up 2 7/8" tubing and continue in hole. Tagged up at 400'. Drill cement to 450' and fall free. Continue in hole and tagged at 810'. Drill cement and stringers down to 975'. Fall free and continue in hole to 1450'. Tagged cement stringers. Drill cement stringers and clean out hole down to 2090'. Circulate hole clean with water. Shut down and release pulling unit and reverse equipment.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Gene Lee TITLE Agent DATE 9-22-93
TYPE OR PRINT NAME Gene Lee TELEPHONE NO. 622-7355

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT I SUPERVISOR TITLE DATE SEP 27 1993

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 27 1993

GOVERNMENT
OFFICE