

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-31986
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2667
7. Lease Name or Unit Agreement Name Ottawa State
8. Well No. 1
9. Pool name or Wildcat Wildcat--Delaware

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator WTI 1993, Ltd.	
3. Address of Operator C/O 1306 Meadow Lane Roswell, NM 88201	
4. Well Location Unit Letter <u>K</u> : <u>1980'</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>3</u> Township <u>22 South</u> Range <u>32 East</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3797' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input checked="" type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

August 31, 1993

Move in reverse equipment. Dig out Cellar and weld on wellhead. Extend 8 5/8 casing and wellhead to ground level. Set Anchors, Rig up pulling unit and spud well at 3:30 PM 8-31-93. Notify NMOC-D-Hobbs of spud. Go in hole with 7 7/8 bit. Drill out surface plug and fall free at 55'. Go in hole and tag cement stringers at 310'. Drill out cement and clean out hole to 400'. Circulate hole clean and pull out of hole. Lay down tubing and drill collars. Nipple down BOP and flange up wellhead. Shut well in. Release reverse and pulling unit.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Gene Lee TITLE Agent DATE 9-1-93  
TYPE OR PRINT NAME GENE LEE TELEPHONE NO. 622-7355

(This space for State Use)

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR TITLE DATE SEP 27 1993  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 23 1993

OFFICE