

## NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

## MISCELLANEOUS REPORTS ON WELLS

Submit this report in triplicate to the Oil Conservation Commission or its proper agent within ten days after the work specified is completed. It should be signed and sworn to before a notary public for reports on beginning drilling operations, results of shooting well, results of test of casing shut-off, result of plugging of well, and other important operations, even though the work was witnessed by an agent of the Commission. Reports on minor operations need not be signed and sworn to before a notary public. See additional instructions in the Rules and Regulations of the Commission.

Indicate nature of report by checking below:

REPORT ON BEGINNING DRILLING OPERATIONS		REPORT ON REPAIRING WELL	
REPORT ON RESULT OF SHOOTING OR CHEMICAL TREATMENT OF WELL		REPORT ON PULLING OR OTHERWISE ALTERING CASING	
REPORT ON RESULT OF TEST OF CASING SHUT-OFF		REPORT ON DEEPENING WELL	
REPORT ON RESULT OF PLUGGING OF WELL	<b>XXXX</b>		

HOBBS, NEW MEXICO

DECEMBER 22, 1942

Place

Date

OIL CONSERVATION COMMISSION,  
SANTA FE, NEW MEXICO.

Gentlemen:

Following is a report on the work done and the results obtained under the heading noted above at the

**FELMONT CORPORATION**

STATE

Well No. **1** in theCompany or Operator  
**Center of Log 11**of Sec. **5**, T. **21S**

Lease

, R. **35E**, N. M. P. M.,**Wildcat**Field, **Lea**

County.

**12-22-42**

The dates of this work were as follows:

**12-21-42**

19

Notice of intention to do the work was (was not) submitted on Form C-102 on

and approval of the proposed plan was (was not) obtained. (Cross out incorrect words.)

**TD 3717'** DETAILED ACCOUNT OF WORK DONE AND RESULTS OBTAINED  
**S.L.M. - Dry hole. Plugged and abandoned.**

Run 15 sacks cement on bottom of hole ( quickset cement), then filled hole with mud with sand and gravel cap to 1750'. (Top salt 1802'). Cemented with 25 sacks cement from 1750' to 1690', quickset cement by Halliburton method, let cement set then filled hole with mud to within 4 feet of top of 10-3/4" casing used for surface casing. Put in cement cap with 4" pipe marker set in cement. Marker extends 5 feet above ground surface. Dry hole plugged and abandoned.


**R P COATS****COATS DRILLING COMPANY**

Witnessed by \_\_\_\_\_ Name \_\_\_\_\_ Company \_\_\_\_\_ Title \_\_\_\_\_

Subscribed and sworn before me this \_\_\_\_\_

**22**

day of

**December**, 19 **42**


Notary Public

My commission expires

**Dec 17, 1944**

I hereby swear or affirm that the information given above is true and correct

Name

**R P Coats** **D.C. Coats**

Position

**Drilling Contractor** **Temporary field**

Representing


**Felmont Corporation** **Representative**

Company or Operator

Address

**1213 Commerce Bldg, Houston, Texas**

Remarks:



Name

Title