

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-7

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
E-8241

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator <u>Ernie L. Hegwer</u>	8. Farm or Lease Name <u>State 334</u>
3. Address of Operator <u>P.O. Box 1637, Hobbs, NM 88240</u>	9. Well No. <u>3</u>
4. Location of Well UNIT LETTER <u>H</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>East</u> LINE, SECTION <u>3</u> TOWNSHIP <u>21S</u> RANGE <u>35E</u> NMPM.	10. Field and Pool, or Wildcat <u>Eumont V-SR-Qu</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3587 GR</u>	12. County <u>Lea</u>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rig up and drill out to TD of 3900'. Circulate hole clean, spot 800 gals. 15% NEFE over interval. Perforate 3852-3864 2 shots per foot, total of 13 shots. Run packer and set @ 3900'. Acidize with 800 gals. 15% NEFE acid and flush. Swab well down. Run rods and tubing, place well on production. Recovering acid water.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Ernie L. Hegwer</u>	TITLE <u>Owner</u>	DATE <u>9-21-88</u>
APPROVED BY <u>Paul Kautz</u> Geologist	TITLE _____	DATE <u>SEP 21 1988</u>
CONDITIONS OF APPROVAL, IF ANY:		

SEP 2 1964