

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-8504
7. Lease Name or Unit Agreement Name CHARM STATE
8. Well No. 2-36
9. Pool name or Wildcat Lease JALMATAYATES 7 RIVERS

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator JOHN YURONKA	3. Address of Operator ONE MARIENFELD PLACE, STE 580 MIDLAND, TX 79701	4. Well Location Unit Letter I : 1980 Feet From The SOUTH Line and 660 Feet From The EAST Line Section 36 Township 21-S Range 35-E N14PM LEA County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3621' GR
--	-------------------------------------	---	---	--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

THIS WELL HAS 8 5/8" CASING SET @ 310' WITH CEMENT CIRCULATED TO SURF. 5 1/2" CASING @ 3821' CEMENTED WITH 175 SX.

1. PULL ALL PRODUCTION EQUIPMENT.
2. SET CIBP @ 3400'. DUMP 10 SX CEMENT ON TOP.
3. LOAD 5 1/2" CASING WITH MUD LADEN FLUID.
4. WELD ONTO 5 1/2" CASING & SHOOT CASING OFF @ 2000'+-. PULL & LAY DOWN 5 1/2" CASING.
5. TIH WITH TUBING. SPOT 50 SX CEMENT PLUG 2000' - 1860'.
6. SPOT 50 SX CEMENT PLUG 350' - 210'.
7. SPOT 10 SX CEMENT PLUG @ SURF.
8. INSTALL DRY HOLE MARKER.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE John Yuronka TITLE AUTHORIZED AGENT DATE 2/17/92
TYPE OR PRINT NAME JOHN YURONKA TELEPHONE NO. 683-3344

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: