

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ For ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name H. C. Collins
3. Address of Operator P. O. Box 670, Hobbs, NM 88240	9. Well No. 3
4. Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>14</u> TOWNSHIP <u>21S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat Funice Monument
15. Elevation (Show whether DF, RT, GR, etc.) 3560' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Repair Casing Pressure	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with production equipment. Set RBP at 3000', test 500#. Place 10' frac sand on RBP. Perf at 1475' with (4) 1/2" JH - 90° phased. Set cement retainer at 1300', test tubing 3000#. Pump 150 sacks Class "C" with 4% gel and 50 sacks Class "C" neat. Squeeze. Reverse excess cement. Drill out cement and cement retainer, test casing 500#. Wash sand off RBP and POH with RBP. Clean out if necessary. GIH with tubing. Run rods and pump, hang well on.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James H. Howard TITLE Area Engineer DATE 10-19-82

APPROVED BY JERRY BEATON TITLE DISTRICT SUPERVISOR DATE OCT 21 1982