Summarized Restoration Procedure:

EMSU #363 was shut-in after having a stuck pump. This restoration was designed to reactivate the well from its shut-in status by re-running the tubing, pump, and rods into the existing wellbore for further production.

- 1) MIRU pulling unit. NU BOP.
- 2) RIH with production tubing. ND BOP.
- 3) RIH with new pump and rods.
- 4) Space out and clamp off.
- 5) Hang well on and RD pulling unit.
- 6) Test pump and put back on production.
- 7) Notify field office personnel of well status.