

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

3-NMOCD-Lea County
 1-RH-Engineer
 1-PB-Engineer
 1-CM-Foreman
 1-File

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease
 State ☒ Fee ☐
 5. State Oil & Gas Lease No.
 B-1889

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE APPLICATION FOR PERMIT - M (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER-

2. Name of Operator
 Getty Oil Company

3. Address of Operator
 P. O. Box 730 Hobbs, New Mexico 88240

4. Location of Well
 UNIT LETTER O 660 FEET FROM THE South LINE AND 1980 FEET FROM
 THE East LINE, SECTION 16 TOWNSHIP 21-S RANGE 36-E N.M.P.M.

7. Unit Agreement Name

8. Farm or Lease Name
 State "D"

9. Well No.
 2

10. Field and Pool, or Wildcat
 Eunice-Mon (GR-SA)

15. Elevation (Show whether DF, RT, GR, etc.)
 3623' DF

12. County
 Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

| | | | |
|---|---|--|---|
| NOTICE OF INTENTION TO: | | SUBSEQUENT REPORT OF: | |
| PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> | PLUG AND ABANDON <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOBS <input type="checkbox"/> | |
| | | OTHER <input type="checkbox"/> | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up pulling unit and pull rods and pump.
2. Install BOP and pull tubing.
3. GIH with bit and collars and clean open hole 3809-3883.
4. TOH.
5. GIH with hydrojet and jet open hole section.
6. TOH.
7. GIH with workstring and packer, set packer at 3700'.
8. Acidize open hole as per recommendation.
9. TOH with packer and work string.
10. GIH with tubing, pump, and rods.
11. Return well to production and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dale E. Crockett TITLE Area Superintendent DATE 8/17/81

APPROVED BY [Signature] TITLE [Signature] DATE SEP 3 1981

CONDITIONS OF APPROVAL, IF ANY: