

Do not pump more than 18 bbls flush. Pull out of cmt ret. and reverse circ. tbg clean.

- ⑨ Wait on cmt 12 hrs or until a compressive strength of 1000 psi is achieved.
- ⑩ Drill up cmt & cmt retainer from 3120'-3350'. Test squeeze to 500 psi. Re-sgz if necessary.
- ⑪ Drill up cmt & cmt retainer from 3495' to 3730'. Test squeeze to 500 psi. Re-sgz if necessary.
- ⑫ Drill up CIBP @ 3730'. Run bit to TD @ 3920'. Circ. hole clean. Set pkr @ 3750' or deeper and test csq to 500 psi. Sgz csq leak if one is found.
- ⑬ Rig down. This well is to be turned over to Chevron as part of the Eunice Monument South agreement.