Submit 3 Copies

State of New Mexico

Form C-103

to Appropriate District Office Er., Ay, Minerals and Natural Resources Department Revised 1-1-89 OIL CONSERVATION DIVISION DISTRICT WELL API NO. P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 DISTRICT II Santa Fe, New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease STATE FEE X 1000 Rio Brazos Rd., Aztec, NM 87410 6. State Oil & Gas Lease No. SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Salt Water OIL GAS onner Disposal Well WELL WELL Atha "M" Name of Operator 8. Well No. McCasland Disposal System 3. Address of Operator 9. Pool name or Wildcat P. O. 98, Eunice, NM 88231 Jalmat Yates SR Queen 4. Well Location 660 South 660 Unit Letter Feet From The West Feet From The Line and Line 31 36E Lea Section Range **NMPM** Township County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. **NOTICE OF INTENTION TO:** SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON **REMEDIAL WORK ALTERING CASING CHANGE PLANS TEMPORARILY ABANDON** COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT **PULL OR ALTER CASING** CASING TEST AND CEMENT JOB OTHER: OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. 1. MIRU PU. Install BOP. Release pkr. POOH w/ plastic-lined tubing. 3. PU Bit & Drill Collars. RIH & clean out open hole from 3752' - 3872'. RIH w/ RBP & set @ 3713' +. Dump 2 sks. sand. POOH. PU retrievable pkr. RIH & test RBP to 500#'s. 6. Hunt hole in 5 1/2" csg; get injection rate, pump press. Determine cement quality then. Squeeze hole. POOH. WOC. RIH w/ bit & DC's. DO cement test csg. to 500#'s for 30 min POOH & lay down DC's. 8. RIH & wash sand off RBP. Retrieve RBP & POOH. RIH w/ AD-1 pkr. on 2 3/8" plastic lined tbg. Pump pkr. fluid. Set pkr. @ 3713'. 9. 10. Return to injection. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Company Representative Ray D. Ramsey **TELEPHONE NO. 393-3189** TYPE OR PRINT NAME

TITLE

(This space for Stronginal SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR

FFB 23 1994

DATE

APPROVED BY CONDITIONS OF APPROVAL, IP ANY: