

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88241-1980

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-04930
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	ARROWHEAD GRAYBURG UNIT
8. Well No.	126
9. Pool name or Wildcat	ARROWHEAD; GRAYBURG
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER INJECTOR	
2. Name of Operator Chevron U.S.A. Inc.	
3. Address of Operator P.O. Box 1150, Midland, TX 79702	
4. Well Location Unit Letter <u>E</u> : <u>1980</u> Feet From The <u>NORTH</u> Line and <u>660</u> Feet From The <u>WEST</u> Line Section <u>36</u> Township <u>21S</u> Range <u>36</u> NMPM LEA County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: RUN POLYBORE LINER ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

RUN CSG SCRAPER TO 3100', SWAB BELOW 3100'. SET INFLATABLE BP @ 3000'. RUN LINER INTO CSG TO TOP OF INFLATABLE BP. SET DRILL COLLARS ON BP. CONTINUE TO RUN INTO WELLBORE, SETTING LINER DOWN ON PKR; CONTINUE RUNNING INTO WELL TO REGAIN ELONGATION AND STRETCH. WHEN POLYETHYLENE IS SET, CUT LINER @ TOP OF WH OR BOP. INSTALL FLANGE ON WH & FUSE FLANGE TOP TO LINER. CIRC WARM WATER THROUGH WELL TO ENABLE POLYETHYLENE TO PUSH ITSELF INTO COLLARS. PERFORM MIT. POH W/BP. RIH W/INJECTION EQPT, PKR @ 3700'. REPAIR IPC AS NEEDED. PERFORM MIT. RETURN WELL TO INJECTION.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. K. Ripley TITLE TECHNICAL ASSISTANT DATE 11/24/97
TYPE OR PRINT NAME J. K. RIPLEY TELEPHONE NO. (915)687-7148

(This space for State Use)

ORIGINAL SIGNED BY CHRIS WILLIAMS
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE 11/24/97
CONDITIONS OF APPROVAL, IF ANY: