

State of New Mexico  
Energy, Minerals and Natural ResourcesOIL CONSERVATION DIVISION  
1220 South St. Francis Drive  
Santa Fe, NM 87505FORM C-103  
Revised March 25, 1999

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. <b>30-025-06549</b>
1. Type of Well <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		5. Indicate Type of Lease <input type="checkbox"/> STATE <input checked="" type="checkbox"/> FEE
2. Name of Operator <b>Apache Corporation</b>		6. State Oil & Gas Lease No.
3. Address of Operator <b>2000 Post Oak Blvd., Ste. 100, Houston, Texas 77056-4400</b>		7. Lease Name or Unit Agreement Name <b>Chesher</b>
4. Well Location Unit Letter <b>K</b> : <b>1980</b> Feet From The <b>South</b> Line and <b>1980</b> Feet From The <b>West</b> Line Section <b>12</b> Township <b>21S</b> Range <b>37E</b> NMPM <b>Lea</b> County		8. Well No. <b>1</b>
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <b>3465' GR</b>		9. Pool name or Wildcat <b>Wantz Abo</b>

11. NOTICE OF INTENTION TO: <input type="checkbox"/> Perform Remedial Work <input type="checkbox"/> Plug and Abandon <input type="checkbox"/> Temporarily Abandon <input type="checkbox"/> Change Plans <input type="checkbox"/> Pull or Alter Casing <input type="checkbox"/> Other		Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data SUBSEQUENT REPORT OF: <input type="checkbox"/> Remedial Work <input type="checkbox"/> Altering Casing <input type="checkbox"/> Commence Drilling Operations <input checked="" type="checkbox"/> Plug and Abandonment <input type="checkbox"/> Casing Test and Cement Job <input type="checkbox"/> Other	
--	--	--	--

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

4/10/2002    Move in and rig up. Nipple up BOP.

4/11/2002    Run in hole and tag top of cement @ 5244' on CIBP set @ 5280'. Circulate hole w/ mud. Pull up hole to 3300' and spot cement plug w/ 250 sx. Wait on cement.

4/12/2002    Run in hole and tag top of cement @ 2351'. Spot cement plug @ 1450' w/ 75 sx. Spot cement plug @ 270' w/ 75 sx. Wait on cement. Tag top of cement plug @ 85'. Spot cement plug @ 60' to surface w/ 50 sx. Install P&A marker and clean location.

Approved as to Plugging of the Well Bore.  
 Liability under bond is retained until  
 Surface restoration is completed.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Debra J. Anderson TITLE Sr. Engineering Technician DATE 4/29/2002

TYPE OR PRINT NAME Debra J. Anderson TELEPHONE NO. 713-296-6338

(This space for State Use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

ORIGINAL SIGNED BY

GARY W. WINK

OC FIELD REPRESENTATIVE II/STAFF MANAGER

DATE

FEB 11 2003

GWW