

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-814-1

5. LEASE DESIGNATION AND SERIAL NO.
L 0032096-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Continental Oil Company

3. ADDRESS OF OPERATOR
Box 160, Hobbs, N. Mex. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
*1980' FSL & 1980' FWL of sec. 13, T-21S,
R-37E, Lea County, N. Mex.*

14. PERMIT NO. *R-37E* 15. ELEVATIONS (Show whether DF, RT, CR, etc.)

7. UNIT AGREEMENT NAME
N. M. 9.21

8. FARM OR LEASE NAME
Lockhart B-13A

9. WELL NO.
4

10. FIELD AND POOL, OR WILDCAT
Terry - Blindly

11. SEC., T., R., M., OR B.L. AND
SURVEY OR AREA
sec. 13, T-21S, R-37E

12. COUNTY OR PARISH *Lea* 13. STATE *N. Mex.*

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) *Convert to a salt water disposal* ☒

PULL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to convert this well to a salt water disposal well by the following method:

- 1) Set CIBP on wireline at approx 5150' with 1 sack cement.
- 2) Perforate from 4510' to 5125'.
- 3) Treat perforations with 5500 gals. of 15% HCL acid.
- 4) Run 3" plastic lined tubing with packer, and set packer at approx. 4475'.
- 5) Hook-up well for water disposal.

18. I hereby certify that the foregoing is true and correct

SIGNED *M. E. Gordon* TITLE *Adm. Section Chief* DATE *9-16-68*

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE *APPROVED*

SEP 17 1968

*See Instructions on Reverse Side

J. L. GORDON
ACTING DISTRICT ENGINEER