

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator <b>Shell Oil Company</b>	5. State Oil & Gas Lease No.
3. Address of Operator <b>P. O. Box 1509, Midland, Texas 79701</b>	7. Unit Agreement Name
4. Location of Well UNIT LETTER <b>M</b> , <b>400</b> FEET FROM THE <b>South</b> LINE AND <b>550</b> FEET FROM THE <b>West</b> LINE, SECTION <b>15</b> TOWNSHIP <b>21S</b> RANGE <b>37E</b> NMPM.	8. Farm or Lease Name <b>Argo</b>
	9. Well No. <b>12</b>
	10. Field and Pool, or Wildcat <b>Wantz Abo</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3444 DF</b>	12. County <b>Lea</b>

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> <b>Recomplete in Wantz Abo</b>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Cement squeeze San Andres perforations 3972' to 3985' with 50 sx cement.
2. Drill out cement and CIBP at 4200'.
3. Run GR Sonic log and perforate Wantz Abo at intervals selected from log.
4. Acidize and complete as warranted.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *A. E. Cordray* TITLE **A. E. Cordray, Staff Engineer** DATE **4-24-73**  
APPROVED BY *Leslie A. Clements* TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: