

No tag. PU to 2387. Lower tbg to 3007, no tag. Pump 50 bbl 10# brine. No circ 5! or 9-5/8. Mixer pump 50 sks Class "C" 3007-2567. Pull to 2000. WOC 4 hrs, Lower tbg to 3007. No tag. POH w/2-3/8. Set 5-1/2 CIBP at 2775. RIH w/2-3/8 to 2768'. Mix & spot 10 sks Class C. PU to 2100. Finish out of hole w/2-3/8. RIH w/ 5-1/2 Sun Rdg & 2-3/8 set @ 2015. Press down tbg to 1000#. Held test csg 2015 to surf, 1000# ok. Rise pkr, POH, Perf 4 way squeeze, shot at 2400. Est circ between 5! & 9-5/8 w/50 bbl 10# brine. RIH w/Baker 5-1/2 cmt ret on 2-3/8 tbg set at 2356. Test tbg 3000#. Mix, Pump 75 sks "C" into perf @ 2400, circ up 9-5/8. Sting out POH w/setting tool and 2-3/8, left 2 bbls cmt on top of ret. Perf 4 way squeeze, shot @ 260'. ND BOP & wellhead Est circ between 5-1/2 & 9-5/8. Mix & pump 100 sks "C" cmt to surf between 5-1/2 & 9-5/8. Test 5! to 1000# ok. Cut off WH. Mix 5 sk surf plug. Instl dry hole marker. RD unit & equip. Clean loc & fill cellar.