

NO. OF COPIES RECEIVED	
DISTRIBUTION	
DATE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name <i>Com</i> Akens "A" Oil Unit	
8. Farm or Lease Name	
9. Well No. 1	
10. Field and Pool, or Wildcat Oil Center Blinebry	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER <input type="checkbox"/>
1. Name of Operator Sun Oil Company		
2. Address of Operator Box 1861, Midland, Texas 79701		
3. Location of Well UNIT LETTER <u>U</u> <u>376</u> FEET FROM THE <u>west</u> LINE AND <u>990</u> FEET FROM <u>south</u> LINE, SECTION <u>3</u> TOWNSHIP <u>21-S</u> RANGE <u>36-E</u> NMPM.		
15. Elevation (Show whether T, GR, etc.) 3592 RT		

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull production equipment.
2. Locate casing leak.
3. Repair casing leak by squeeze cementing.
4. Drill out cement.
5. Perforate 5882, 86, 90, 92, 98, 5900, 06, 10, 16, 18, 20, 45, 61, 64, 69, 76, 78, 83, 97, 6048, 50, 69, 76, 78, 83, 86, 6118, 20, 26, 29, 3337 & 89.
6. Acidize w/11,000 gal.
7. Place on production and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed by <i>Chas. Gray</i> for B. T. Goza	TITLE <u>Petroleum Engineer</u>	DATE <u>5-1-74</u>
APPROVED BY <u>Joe D. Ramsey</u>	TITLE <u>Dist. I, Supv.</u>	DATE <u>5-1-74</u>
CONDITIONS OF APPROVAL, IF ANY:		

U.S. DEPARTMENT OF AGRICULTURE
BUREAU OF PLANT INDUSTRY
WASHINGTON, D. C.