

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		
1. Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/> Triple		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Atlantic Richfield Company		Sarkeys
3. Address of Operator		9. Well No.
P. O. Box 1710, Hobbs, New Mexico 88240		4
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>P</u> <u>990</u> FEET FROM THE <u>East</u> LINE AND <u>330</u> FEET FROM THE <u>South</u> LINE, SECTION <u>23</u> TOWNSHIP <u>21S</u> RANGE <u>37E</u> NMPM.		Blinebry Oil
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3390' GR		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 7275', PBD 7232'. Presently completed in Blinebry perfs 5730-5883'.
Propose to add Blinebry perfs & treat in the following manner:

1. Kill well & install BOP. Pull completion assy.
2. Add Blinebry perfs w/1 - .43" JS ea @ 5547, 54, 70, 79, 88, 5602, 07, 25, 38, 69, 75, 86, 91 & 5698'.
3. Treat old Blinebry perfs 5730-5883' w/2000 gals 15% HCl & ball sealers.
4. Treat new Blinebry perfs 5547-5698' w/35,000 gals gelled 9# brine plus 47,500# 20/40 sd and ball sealers.
5. Lay down frac tbg. Swab & test. Rerun completion assy & return all Blinebry perfs to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. J. B... TITLE Dist. Drlg. Supv. DATE 11/21/74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

NOV 20 1971

CL CONSERVATION COMM.
FALLS, N. H.