

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-7574	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Sinclair Oil & Gas Company		South Wilson Deep Unit
3. Address of Operator		9. Well No.
Shell Oil Company (Western Division) P. O. Box 1509, Midland, Texas		2
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>J</u> , <u>1980</u> FEET FROM THE <u>south</u> LINE AND <u>1980</u> FEET FROM		Grama Ridge (Morrow)
THE <u>east</u> LINE, SECTION <u>33</u> TOWNSHIP <u>21S</u> RANGE <u>34E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3656' DF		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to recompleate from Bone Spring to Morrow Gas.

1. Pull tubing and packer.
2. Squeeze off Bone Spring perforations 10,675' - 10,711'.
3. Clean out and complete in the Morrow Gas.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Shell Oil Company Sub-Operator and Agent

SIGNED J. D. Duren J. D. Duren TITLE Staff Petrophysical Engineer DATE September 30, 1966

APPROVED BY [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: