

Procedure - Continued:

7. Spot 45 sacks of cement at 1,900' - 1,800'.
8. Spot 45 sacks of cement at 1,163' - 1,063'.
9. Spot 20 sacks at 53' - 3'.