

San Simon 32A St. Com
Well No. 1
East Grama Ridge Morrow
Lease No. E-1924
API No. 30-025-27306
Lea County, NM
Form: C-103
Page 3.

09-03-93 Run in hole w/Alpha 4.5 CIBP & set @12,705' & dump 35' of cement on top. Trip in hole w/2.875 tubing open ended/CTSN to 9312'.

09-04-93 Trip out of hole w/2.875 tubing. Perf Wolfcamp Zone @11,198-210'; 11,301'; 11,310'; 11,313'; 11,317'; 11,322'; 11326-334' 2 SPF.

09-05-93 RU. Pick up Howco 4.5 pkr. & RBP trip in hole testing 2.375 & 2.875 tbg. to 8000# above slips to 11,375'. Set RBP. POOH w/pkr. to 11,150'.

09-07-93 GIH w/pkr. to 11,370' (RBP @11,375'). Test RPB to 1000 psi O.K. POOH to 11,266', Set pkr. RU Swab and swab tbg. DN to 10,000', Btm of 2-7/8" tbg. @10,435'.

09-08-93 Acidize lower Wolfcamp perfs 11,301-34' w/100 gals. 15% NeFe HCL & 900 gals 7-1/2% NeFe HCL.

09-09-93 Release pkr. @11,266. GIH to 11,375', retrieve RBP, POOH to 11,276', reset RBP @11,276'. Set pkr. @11,275'. Test RBP to 1000 psi O.K. Release pkr. & Pooh to 11,142', set pkr. & test csg. to 500 psi O.K.

09-10-93 Acidize upper Wolfcamp Perfs 11,198-210' w/100 gals 15% NeFe & 600 gals 7-1/2% NeFe HCL.

09-11-93 Swab.

09-16-93

09-17-93 Acidize perfs. 11,198'-11,210' w/8,000 gals purgel III, followed by 3,000 gals. 15% fercheck SC Acid.

09-18-93 Swab.

to

09-21-93

09-25-93 Releasing pkr./lower tubing & release RBP. Trip out of hole w/2.875 tubing.