

8. Swab fluid to 3000'.
9. ND BOP/manifold system. NU tree and test to 10000 psi.
10. Perf interval 13153-158' w/ 2 SPF (6 ft.-12 holes).
11. Flow well. Test & evaluate.
12. If necessary, treat w/ 1800 gals 15% NEFE HCL w/ 1000 SCF
N2/bbl in acid & flush. Max rate/press - 10BPM, 10000 psi.
13. Place well on production.