

¹¹ Describe the proposed program. If this application is to DEEPEN or PLUG BACK give the data on the present productive zone and proposed new productive zone. Describe the blowout prevention program, if any. Use additional sheets if necessary.

6. Drill cement plug & clean out to cement plug @ 8,600'
7. Test casing to 1,500# psi for 30 min.
8. Lay down re-entry pipe & tools
9. Release rig
10. Prepare for completion