

Form 3160-5
November 1983)
Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N. M. OIL WELL
P. O. BOX
HOBBS (Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. NM-86710
2. NAME OF OPERATOR Phillips Petroleum Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 4001 Penbrook Street, Odessa, TX 79762		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface Unit D, 660' FNL & 660' FWL		8. FARM OR LEASE NAME Luke Federal
14. PERMIT NO. 30-025-31442		9. WELL NO. 2
15. ELEVATIONS (Show whether SP, NT, GR, etc.) 3672' GR		10. FIELD AND POOL, OR WILDCAT Lost Tank (Delaware)
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 31, 21-S, 32-E
		12. COUNTY OR PARISH Lea
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other) TA'd Wellbore

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

7-28-93 - Unseat pump and POOH with rods and sucker rod pump. Remove wellhead assembly and install BOP. Unseat tubing anchor and pull 226 jts. of 2-7/8" tubing from well.

7-29-93 - WIH w/5-1/2" CIBP on 2-7/8" tubing to depth of 7035' and set. Tested CIBP to 1,000# for 30 mins. Test O.K. POOH w/2-7/8" tubing. Removed BOP. Install wellhead with valve and bullplugs.

APPROVED FOR 12 MONTH PERIOD
ENDING 10/13/94

18. I hereby certify that the foregoing is true and correct

SIGNED

L. M. Sanders

TITLE

Supervisor, Reg. Affairs

DATE 9/15/93

(This space for Federal or State office use)

APPROVED BY (ORIG. SGD.) JOE G. LARA

TITLE

PETROLEUM ENGINEER

DATE

10/13/93

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side