

Do I simply shoot some holes through the 4-1/2" and 7" about 4,270' and try to circulate behind the 7"? If I can circulate, place a 100' balanced plug (inside the 4-1/2", and outside the 7") or perhaps use a cement retainer at about 4,170'.

If I can't circulate (or hardly pump in), assume the top is much higher than this and simply spot a 100' plug across 4,170' - 4,270' inside the 4-1/2".

Thanks for your input. I may call you this afternoon.