

3. Cut off csg. Log at 3376'. DO cont to 3586'. Circ Clean.
DO cont from 3586' - 3658'. Test csg & shoe to 1000 psi for 15
min. DO Cal-seal & pea-gravel to 3772'. CO to 3804'. Set
pkv at 3557'. Circ hole w/ Conoco pkv fluid. Test to 500# for
30 min. Acidize pkvs w/ 120 bbls 15% HCl - NE-FE acid in
3 stages. Flush w/ 60 bbls TFW. Flowed & swabbed back 35 bbls.

4. Resume injection.

RECEIVED
MAR 19 1987
CCCD
HOBBS OFFICE