

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-030133 (6)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

N.M.P.U.

8. FARM OR LEASE NAME

South Basin Unit

9. WELL NO.

37

10. FIELD AND POOL, OR WILDCAT

South Basin, Kansas

South

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 28 T-22S R-36E

12. COUNTY OR PARISH

13. STATE

Kan

N. Mex.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ *Water Injection Well*

2. NAME OF OPERATOR
Continental Oil Company

3. ADDRESS OF OPERATOR
P.O. Box 460, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FNL & 660' FEH of Sec. 28

JAN 7 1974

U. S. GEOLOGICAL SURVEY

HOBBS, NEW MEXICO

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GA, etc.)

3517' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) *Convert to Injection*

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

Convert to Injection ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to convert this well to injection by:

- 1. Rig up, tag bottom and tally out.*
- 2. If fill is encountered about 3,810', clean out to 3,813'.*
- 3. Run 2 3/8" cement lined tubing & packer, set packer at $\pm$ 3,630'.*
- 4. Place well on injection.*

This waterflood authorized by N.M.O.C. Order No. B-4068.

18. I hereby certify that the foregoing is true and correct

SIGNED

Robert Gault

TITLE *Division Office Manager*

DATE *1-4-74*

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

JAN 7 1974

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

USGS-S, Partners-21, File