

Emergy King NW #2

#17 cont.

- 5-20: 13 hr SITP 380 psi/ Bled off , no fluid recovery/ 1st swab run, recv  $\frac{1}{2}$  bbl oil,  $\frac{1}{2}$  BLW, FL 3300 (PKR 3500) 1-1 hr FE check, no fluid entry, Rls PKR, Lwr & tag frac sand 3602, POH w/ tbg and PKR. Ran Hydro-bailer on 2-7/8" tbg, clean out sand 3602-3732 in 2 runs/ SDFN/
- 5-22: RIH w/ Hyd-Bailer on 2-7/8" WS, cln out SD 3732-3764 PBD, POH to 3670, wait  $\frac{1}{2}$  hr, lower & tag PBD 3764, no fill/ POH & lay dwn 2-7/8" WS & Hyd-Bailer/ RIH w/ 2-3/8" tbg, POH & Lay dwn 2-3/8" tbg/ SDFN/ Prep to change out tbg, RIH w/ prod set up.
- 5-23: RIH w/ 2-3/8" pumping set up, TS 3590, MA 3659, Perf sub 3555, SN 3554, RIH w/ 2 x 1 $\frac{1}{4}$  x 12' pump & rods (hung well on) check pump action, Rig down RR 3:30 pm 5-22-84. Put well on test.