

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

7-18-66

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name J. F. Janda (NCT-I)
3. Address of Operator P. O. Box 670, Hobbs, New Mexico 88240	9. Well No. 6
4. Location of Well UNIT LETTER B 660 FEET FROM THE north LINE AND 1980 FEET FROM THE east LINE, SECTION 2 TOWNSHIP 23S RANGE 36E NMPM.	10. Field and Pool, or Wildcat Langlie-Mattix
15. Elevation (Show whether DF, RT, GR, etc.) 3462' GL	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐ CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒
CASING TEST AND CEMENT JOB ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

3796' PB. Rigged up pulling unit, installed BOP and pulled out of hole. Ran 5 1/2" Baker CI BP on 2-3/8" tubing and set at 3615'. Loaded hole with mud. Spotted 10 sacks cement on top of BP. Tested 5 1/2" casing and BP with 500# 30 minutes, no drop in pressure. Pulled tubing and spotted 10 sacks cement plug 80' to surface. Set dry hole marker and cleaned location. Plugged and abandoned 7-14-66.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY

SIGNED C. D. BORLAND

TITLE Area Production Manager

DATE 7-18-66

APPROVED BY John W. Runyan

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY:

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION C. C.

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAY 6 2 53 PM '66

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	B-229

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name J. F. Janda (NCT-I)
3. Address of Operator Box 670, Hobbs, New Mexico	9. Well No. 6
4. Location of Well UNIT LETTER B 660 FEET FROM THE North LINE AND 1980 FEET FROM East 2 TOWNSHIP 23-S RANGE 36-E N.M.P.M. THE East LINE, SECTION 2 TOWNSHIP 23-S RANGE 36-E N.M.P.M.	10. Field and Pool, or Wildcat Langle Mattix
15. Elevation (Show whether DF, RT, GR, etc.) 3462' GL	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

OTHER **Plug and abandon**

EXXIMPT

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 3800', PBTD 3796'.

It is proposed to plug and abandon as follows:

- 1. Pull tubing.**
- 2. Run CI BP on tubing and set at approximately 3630'.**
- 3. Test casing and BP with 500#.**
- 4. Circulate hole with mud (approximately 90 barrels).**
- 5. Spot cement plug (10 sacks) over BP.**
- 6. Pull tubing to 50' and spot 7 sack cement plug to surface.**
- 7. Install dry hole marker and clean location.**

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY
C. B. BOPLAND

Area Production Manager

May 5, 1966

SIGNED

TITLE

DATE

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: