

Stevens B #7
30-025-09328

Recommendation to Temp. Abandon

This well is currently inactive. It is recommended that the well be temporarily abandoned in order to evaluate possible up-hole potential.

1. POOH w/ rods and tubing.
2. Make scraper run inside 4.5", 9.5# casing to 3640'.
3. Set Cast Iron Bridge Plug w/in 50' of top of perfs @ 3590', spot 35' cmt on top of CIBP.
4. Circulate Casing with inhibited packer fluid.
5. Pressure test casing to 500# for 30 minutes. Give BLM 24 hrs notice prior to pressure test.

RECEIVED

JUN 30 '99

BLM
ROSWELL, NM

