

WORKOVER PROCEDURE
Paddock Unit #24 (cont.)

15. POH with PFT equipment and RIH with production tubing and pumping BHA (contact Jesse Naranjo @ 688-6751 for A/L procedure).

16. PMOP.

Note the following safety guidelines when acidizing with a PFT tool:

- Flexible treating hose should be adequately supported with chains or cables in case it should part.
- Keep ALL PERSONNEL off rig floor and at a safe distance while tubing and treating hose are being moved or acid is being pumped. In addition, keep personnel a safe distance from all treating and discharge lines while acid is being pumped.
- Pump a 5 bbl brine spacer before breaking any connections.
- All personnel should wear safety goggles.

5/1/90
JTC
S/7/90

h/m/b
Operations Superintendent
Date 5/1/90

Note: please track costs for this workover on attached "Well Work Cost Stewardship" form. If a supplement becomes necessary, fax copy of completed form to Subsurface Engineer.

