

8. Set pkr. @ 6290' Acidize Drinkard perms. 6366'-6578' W/5000 gals. 20% NE Acid in 5 stages using 2000 gals. gel pad ahead of each stage & 500# rock Salt between each stage. Flush W/35 Bbls. 2% KCl Water.
9. Ran 2 3/8" Tubing & Set @ 6450'. Install pumping equipment. Return Drinkard to Shut-In Status, 10-1-82.