

AMENDMENTS:

1. Bottom plug should be 50 sacks minimum. Top of plug should be touched to assure it is in place.
2. Place additional 35-sack plug at 5900-6100 feet.
3. Place additional 35-sack plug at 5000-5200 feet.
4. Place additional 35-sack plug at 3600-3800 feet.
5. Place additional 50-sack plug at 1100-1230 feet.
6. If 7" casing cannot be pulled below 2500 feet place 35-sack plug inside 7" at 2500-2700 feet.