

14. Flowed & swabbed back load fluid. TOH w/ PBP & PKR.
15. RU Welex. Perf U. San Andres 3882-90, 3940-48, 3978-88, 4015, 4030-37, 4052-57, 4094-98, 4110-14, 4122-25, 4129-34, 4144-48, 4154-61, 4196-4204, 4216-20, 4224-26, 4242-48, 4270, 4300, 4304-08 @ 1 SPF.
16. TIH w/ PBP & PKR. Isolate U. San Andres perfs. Acidized perfs w/ 5600 gal of 15% NEFE acid in 3 stages. Flowed & swabbed back 75 Bbls load wtr & spent acid.
17. RU Dresser Titan. Treated U. San Andres zones w/ 14,000 gal of 20% HCL and 739,000 SCF N₂ ISDP 1600#. Flowed and swabbed 230 Bbls load wtr and spent acid. TOH w/ RBP & PKR.
18. Ran 144 jts 4700' of 2 7/8" tbg. Ran 2 1/2" X 2" X 16' SSP on 3/4" and 7/8" rods POP @ 4:00 P.M. 1-8-85.
19. Tested 70 BO 385 BW 1-9-85