

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-3480-1

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name R. E. Col (NCT-A)
3. Address of Operator P. O. Box 670, Hobbs, NM 88240	9. Well No. 2
4. Location of well UNIT LETTER <u>L</u> , <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Penrose Skelly
15. Elevation (Show whether DF, RT, GR, etc.) 3408' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with rods, pump & tubing. Set CIBP at 3480'; circulate abandonment mud, spot 35' cement on top of CIBP. Spot 100' of cement from 3050' to 2950'. Perf 5 1/2" casing at 1200' with (4) 1/2" 90° phased JHPF. Set cement retainer at 1150'. Cement 5 1/2" - 9-5/8" casing casing annulus with 300 sacks "C" neat cement. Pull out of cement retainer, reverse out excess cement. Spot 10 sacks of cement in 5 1/2" casing (approximately 85' to surface) for surface plug. Place a dry hole marker on the well. Clear and clean location as required.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED RD Pater TITLE Area Engineer DATE 8-5-80

APPROVED BY Jerry Seston TITLE DATE 8-5-80
CONDITIONS OF APPROVAL, IF ANY: Expires 2/6/81